

# 1958 IMPALA & BEL AIR SIDE MOLDING CLIP PACKAGE

These are the 8 packages which contain nuts, bolts, and screws which are used to attach the exterior side molding to your 1958. Each bag is numbered and will match the corresponding description listed below.



## #1 The S" Molding

(The molding that goes around the taillights)  
20 - Small T-Bolts (58-1497)  
20 - Nuts

## #2 The Quarter Side Z-Molding

2 - Small T-Bolts (58-1497) (TOP)  
2 - Medium Adjustable T-Bolts (58-1496) (BOTTOM)  
4 - Nuts

## #3 The Fender Spear

12 - Large T-Bolts (58-1494)  
4 - Small T-Bolts (58-1497)  
2 - Medium Adjustable T-Bolts (front) (58-1496)  
18 - Nuts

## #4 The Lower Quarter Side Moldings

32 - Bath Tub Clips (58-1478)  
2 - Small T-Bolts (58-1497)  
2 - Nuts

## #5 The Door Moldings

20 - Bath Tub Clips (58-1478)  
8 - Door End Clips (58-1486)  
8 - Screws

## #6 The Quarter Script

12 - Barrel Clips (square slip clips)

## #7 The Pitchfork - *For Impala Only*

10 - Pitchfork Clips (58-1483)  
4 - Small T-Bolts (58-1497)  
14 - Nuts

## #8 Upper Quarter Bead Molding

22 - Small T-Bolts (58-1497) (replaces bath tub clips)  
2 - Nuts

DO NOT OVER TIGHTEN THE BATHTUB CLIPS.  
THEY WILL MARK YOUR PANELS  
THEY NEED TO HAVE SOME MOVEMENT TO ASSIST INSTALLING THE MOLDINGS.

## ALSO AVAILABLE

Quarter Union Clip (part# 58-1479) \$15  
Bath Tub Clip Tool (part# 58-1480) \$24.95  
Lower Grill Retainer Clips sets (part# 58-1711) \$7