

1958 Chevy Impala

Convertible Top Switch Template

Line up the template with the bottom of the dash to the left of the steering column.

Drill a 3/8" hole for the switch knob.

Drill a 1/8" hole for the alignment peg on the switch.

Install the switch.

